




C4-MU

User Manual

Technical drawing


USER MANUAL



C4-MU


USER MANUAL

Lock the C4-MU



1. The lock is in the OPEN position
- Enter any 4-digit user code
(Example : 1-1-1-1)
2. Turn the knob to the
CLOSED position
- The user code (1-1-1-1) will
scramble automatically to 0-0-0-0
- The user code has been successfully
stored and the lock device is locked.

Unlock the C4-MU




1. The lock is in the CLOSED position
- Enter the stored user code
(Example : 1-1-1-1)
2. Turn the knob to the
OPEN position
- The user code (1-1-1-1) will
scramble automatically to 0-0-0-0
- The device is now open ready for
the next user and fresh 4-digit
user code.


C4-MU

USER MANUAL


Recovering lost / forgotten code



1. The lock is in the CLOSED position 
- Insert the master key and turn 90° right.



2. Scroll each dial downwards until it stops at a preset number.
- The final code displayed is the current code.



3. Remove the key from the lock.
- Turn the knob to the OPEN position 
- The lock is now ready for the next user.